

GUARANTEE

The Stellar Guarantee covers the product to be free of defects in materials and workmanship for a period of TWO YEARS from the date of original retail purchase. During this period, Stellar will, at our option, repair or replace defective parts of the product, or replace the product, providing the Use, Care and Safety Advice has been followed.

The Guarantee does not cover damage, defect or failure caused by or resulting from accidents, external damage, alteration, modification, abuse, misuse or misapplication.

The Guarantee does not cover any damage caused by taking the appliance apart yourself, or attempting to repair the appliance yourself.

THE PRODUCT IS INTENDED FOR DOMESTIC USE ONLY.

Please keep your Purchase Receipt and contact us directly if you encounter any problems with your product.

HORWOOD SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT (INCLUDING COLOUR FADING, SCRATCHES OR ACCUMULATED DIRT) WITHOUT FOLLOWING THE USE, CARE & SAFETY INSTRUCTIONS.

Note: Due to the introduction of improvements from time to time, the right is reserved to supply products which differ slightly from those illustrated and described in this publication.

Errors and Omissions Excepted.

STELLAR CUSTOMER SERVICES,
HORWOOD, AVONMOUTH WAY, BRISTOL,
BS11 9HX, GREAT BRITAIN

sales@horwood.co.uk
www.stellarcookware.co.uk
Tel: 0117 940 0000



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

FOR DOMESTIC USE ONLY




SLIMLINE

DIGITAL SCALE

INSTRUCTION MANUAL

STELLAR CUSTOMER SERVICES
HORWOOD
AVONMOUTH WAY
BRISTOL BS11 9HX
GREAT BRITAIN


customerservice@horwood.co.uk
www.stellarcookware.co.uk
Tel: 0117 940 0000



Quick Guide

1. Remove the scale from the packaging.
2. Insert batteries (see the 'Replace Battery' section of this manual).
3. Place the scale on flat and firm surface.
4. Touch the "ON/OFF/TARE" button to switch on the scale.
5. When "0" appears on the display, the scale is ready for use.

TOUCH SWITCH OPERATION



To switch ON the scale, Touch the "ON/OFF/TARE" button for 1 second and release.

If you want to TARE the scale to zero, touch the "ON/OFF/TARE" button for 1 second and release.

To switch OFF the scale, touch the "ON/OFF/TARE" button for 3 seconds until the LCD display is switched off.

KG/LB BUTTON

The KG/LB touch button allows you to choose metric (kg-g) or imperial (lb-oz) and aqua measurement metric (ml) or imperial (fl.oz) as your preferred system of measurement. However, you may switch between the four systems at any time without resetting the scale to zero.

TARE FUNCTION

The scale allows you to weigh each additional item as it is added to the scale.

After weighing the first item on the scale and with the item remained on the scale, touch the "ON/OFF/TARE" button to reset the scale to zero. You may then add the second item on the scale and it will show the weight of the second item only. You may repeat the same steps for weighing consecutive items.

WEIGHT

Place the scale on flat and firm surface, this is essential for correct measurement.

Touch "ON/OFF/TARE" button to switch on the scale. As soon as "0" appears, the scale is ready for use.

If you put your own bowl on the scale before switching it on, the weight of the bowl has been included and the display will show "0". You may then put your items onto the bowl for direct weight reading.

When the scale is in use and you want to use your own bowl for weighing, you can simply place the bowl on the scale and touch "ON/OFF/TARE" button to reset to zero.


The maximum weighing capacity of the scale is 5 kg. The display will show "Err" when the scale is overloaded.

AUTO-OFF FUNCTION


You may switch off the scale at any time by touching the "ON/OFF/TARE" button and hold for 3 seconds.

In order to prolong the battery life, the scale will be switched off automatically when the weight reading steady for about 180 seconds.

REPLACE BATTERY

When  blinks on the display, the battery must be replaced. The scale requires 2 CR2032 batteries. The battery compartment is located on the underside of the scale.

To replace the battery, you have to open the compartment cover and remove the used battery. Before you replace the new battery into the compartment, please make sure the battery is installed to the correct polarity (+) / (-). See below.



!! Note: To save our environment, used battery should be disposed responsibly through your local recycling collection point.

MAINTENANCE

DO NOT

Do not immerse the scale in water.

Do not operate the scale with wet hands.

Do not put the scale into the dishwasher.

Do not put items exceeding 5 kg onto the scale as this could damage the scale.

Do not place items on the display part as this could damage the LCD display.

Do not try to open the scale by force.

DO

Always clean the scale with soft damp cloth only.

Always keep out the scale from fire, direct sunlight or acidic substance.

Always store the scale in dry condition.

Always replace new batteries at the same time to maximize the battery life.

WARNING

The normal function of the product may be disturbed by Strong Electro Magnetic Interference. If so, simply reset the product to resume normal operation by following the instruction manual. In case the function could not resume, please use the product in other location.



R602-0023-0214-0000